

REVIVAL™ BALUSTERS

Restore. Renew. Rediscover.



Installation Instructions & User Guide

Please Note:

It is the installer's responsibility to understand and adhere to local building codes and safety requirements, and to obtain all required building permits before installing. Revival™ and your retailer are not liable for improper or unsafe installations of this product.

We recommend 2 people for assembly.

Required Tools for Assembly

- Tape measure
- Miter saw with a high tooth count carbide blade
- Safety glasses
- Power drill with Phillips head driver bit
- Pencil
- Silicone caulk
- 3-inch wood spacer block

Level Railing Instructions:

1. Measure your railing opening from post to post to determine the length of each rail section. (Tip: measure between posts as close to the deck surface as possible for the most accurate measurement).

2. Cut your top and bottom rails to that length and clamp them together. Find and mark the center point of both rails. Starting from the center point, mark the top and bottom rails every 4-1/2 inches.

3. Using a power drill, attach baluster connectors (sold separately) on each mark using the screws provided.

4. Place the bottom rail between your rail posts, supported by a 3-inch block. Secure rail to posts.

5. Apply silicone caulk on the inside of the bottom edge of each baluster to prevent turning or rattling after installation is complete. Place a baluster onto each connector on the bottom rail.

6. Apply silicone caulk on the inside of the top edge of each baluster. Carefully place the top rail over the balusters, making sure each connector is seated correctly on each baluster.

7. Inspect the finished railing to make sure your balusters are spaced properly, then secure the top rail to the posts. Add a cap rail (sold separately) for a finished look.

8. For rail sections longer than 4 feet, we recommend using a support block under the bottom rail. These can be made from leftover rail material. Properly position the support block and toe-nail it (drive the nail at an angle) to the bottom rail and deck board.

Stair Railing Instructions:

Our angled stair rail connectors (sold separately) create an accurate baluster fit for stair angles of 35 degrees.

1. Place your top and bottom rails against your posts, mark them, and cut them to the proper angles.

2. Measure the bottom edge of your top rail and mark the center point. Measure the top edge of your bottom rail and mark the center point. Then line up the two center points and clamp your top and bottom rails together.

3. Starting at the center points, mark the top and bottom rails every 5-1/2 inches.

4. Position a baluster connector on each mark. Note: your top and bottom baluster connectors will be facing opposite directions. Screw each baluster connector in place. To properly set these angled connectors, begin screwing vertically until the screw bites into the wood. Then reposition the screw to the proper angle and tighten. Do not over-tighten, which can move the connector off-center.

5. Place the bottom rail between your rail posts, supported by a 3-inch block. Secure rail to posts.

6. Apply silicone caulk to the inside of the bottom edge of each baluster. Then attach a baluster to each baluster connector.

7. Apply silicone caulk to the inside of the top edge of each baluster. Then carefully attach your top rail to the balusters, making sure each connector is seated correctly on each baluster.

8. Inspect the finished railing to make sure your balusters are spaced properly, then secure the top rail to the posts. Add a cap rail (sold separately) for a finished look.

Cleaning & Care

We recommend cleaning your Revival Balusters 2–3 times a year to prevent corrosion and extend the lifespan of your railing. Clean using a mixture of water and mild detergent (like dish soap) and a soft sponge or cloth. Wet down your balusters with a garden hose, then hand wash them with the soapy water and rinse thoroughly with fresh water.

For railings near saltwater, we recommend more frequent cleaning.

Warranty Information

Your Revival Balusters are covered by a 10-year limited warranty for residential installations or a 5-year limited warranty for any non-residential installation. Please reach out to your retailer for any warranty claims or questions.

Share Photos Of Your Deck Revival!

We would love to see pictures of your finished project and celebrate your amazing new outdoor space with you! Tag **#RevivalRailing** on social media to share your best photos. We especially love to see before & after photos so we can celebrate the transformation!