



# Cable & Fittings Take Off Guide



## Stair Rail








AFCOColumnsAndRailings.com



Helping People Build Better Decks

# 175 / 275 CABLE RAIL






05.2022

## 1 Line Post - End

Line Posts are pre-drilled for the cable. One side will be field drilled to enlarge hole for end fitting.



### End Fitting

Nut and Washers screw onto the treaded end of the cable length. Cap included.



## 2 Line Post - Middle

Line Posts are pre-drilled for the cable. Cable is threaded through the holes.





## 3 Corner Post

Posts are pre-drilled for the cable for level rail. One side to be field drilled to enlarge hole for end fitting.

### Corner Fitting


Reverse thread fitting screws into pre-threaded post holes.








AFCOColumnsAndRailings.com



175 / 275 CABLE RAIL



**5**  
\*Undrilled Posts on stairs must be drilled for cables. After setting first cable hole location, use the AFCO-Tool to quickly position remaining cable holes.

05.2022


1

### Line Post - End

Line Posts are Pre-Drilled for the cable. One side will be field drilled to enlarge hole for end fitting or threaded end.

#### End Fitting


Nut & Washers screw onto the treaded end of the cable length. Cap included.



4

### Line Post - In-Line

Line Posts are Pre-Drilled for the cable.




3

### Blank Post In-Line Landing Transition

Undrilled Posts on stairs landings must be drilled for cables and or fittings.

After setting first cable hole location, use the AFCO-Tool to quickly position remaining cable holes.




4

### Blank Post 90 Degree Landing Transition

Undrilled Posts on stairs landings must be drilled for cables and or fittings.

After setting first cable hole location,

 End Fitting will at the back of the post as shown in the far right image

